# Product Details

PRODUCT IMAGE

Notes:

- Recommend energy alkaline batteries. Please make sure the battery polarity (+、 -) in the right place when installing the batteries.
- Do not leave the product on uneven or unstable surfaces, to prevent damage caused by falling. Please be careful when handling the Outdoor Parts to prevent bump.
- Do not violent shock, vibration, or throw the peephole viewer, do not press hard on the LCD display area, beat or scratch, otherwise it will cause damage to the LCD panel ro leakage.
- Do not place the product on hige-temperature, hige humidity or a lot of dust , salt spray and other harsh environments, do not be exposed, do not be exposed to rain, which may result in malfunction.
- Please take ultra-care to the Wire (FPC) when installig the indoor part, do not pull too hard to prevent the wire (FPC) breaking.

Product features and specifications:

Easy and safety to operation: touch and show big image, peephole will not become dark, can't know people are at home or not

HD image: clear LCD screen, vivid for image, better than traditional one

Easy To Install: simple for installation, even the elders can install in five minutes

Better Recognizable: display smooth and clear images, won't distorted images

Wide Applicable: children, the elderly, poor eyesight, can be simple clearly see the people out of the door

Electricity sacings: use 2 AA batteries, special power management technology (about 2000 times switch watch)

Visitor visiting:Press the Doorbell button,meanwhile playing the ring

Picture–taking: Automatically take the picture of the visitor once press the Doorbell button

Lens 60 degrees can perspective

Weight: About 120 g

0.3 megapixels

Host Size: 13.5 (W) x 8.4 (H) x 2.6 (D) cm

Chird Size: 6.0 (W) x 6.0 (H) x 1.4 (D) cm

COMPOSITE IMAGE

AA AA

PeepHole Host

PeepHole lens   Base Flange

EXPLODED VIEW

①

EN Insert PeepHole lens in the outside of the door.

Insert the PeepHole len through door and insert the guide line through the Base Flange on the inside of the door.

②

③

**EN** When the barrel is snug, rotate the Base Flange until the TOP icon is at 12 o'clock(vertical).

EN Use the Tightening screw included to tighten the PeepHole barrel.

EN Take 2 section 7 AA battery in the PeepHole Host.

-25°

EN Buckle up connecting line and Hold the PeepHole Viewer at a-25 degree counter-clockwise position and insert it onto Base Flange.

Ⓐ

Ⓐ Locking Screw

EN Use the screwdriver to tighten the locking Screw. You are new ready to turn the PeepHole Viewer on.

TF

EN Finised

Insert the TF card, Press the Power button, and check the image on the LCD. Now you can press the power button again a few times to practice cycing through the different viewing modes.